

STANDOFF KIT

Everything you need to mount signs, artwork and displays

MADE in the USA

HERE'S HOW TO ASSEMBLE YOUR KIT

TIP: We recommend 3/8" holes in your material to give you more freedom for aligning your panels.

1/4" hole



*Anchor not required for wood;
Pre-drill a 1/8" hole instead.

1 Level material and use 3/8" holes in the material as a template to mark the mounting surface.



2 Pre-drill 1/4" holes in the surface. Insert **nylon anchors** into the holes and tap them flush.



3 Drive **oval head screws** through **barrels** and into nylon anchors until barrel is snug to surface.



4 Screw **threaded studs** into barrels. Place your panel in position and thread on **caps** until tight.

